174731 1988

NASA/ASEE SUMMER FACULTY RESEARCH FELLOWSHIP PROGRAM

JOHN F. KENNEDY SPACE CENTER UNIVERSITY OF CENTRAL FLORIDA

N3953618 LABORATORY TESTING OF A SUPERCRITICAL HELIUM PUMP

FOR A MAGNETIC REFRIGERATOR

Prepared By:

-12-31

Pao-lien Wang

Academic Rank:

Associate Professor

University and Department:

University of North Carolina

at Charlotte

Engineering Technology

NASA/KSC:

Division:

Mechanical Engineering

Branch:

Special Projects

NASA Counterpart:

Frank Howard

Date:

August 1988

Contract No.:

University of Central Florida

NASA-NGT-60002

TABLE OF CONTENTS

Section	Title
1	INTRODUCTION
2	PURPOSE
3	PUMP TESTING PROGRAM
3.1 3.1.1 3.1.2 3.1.3 3.1.4	TESTING SYSTEM The Supercritical Helium Pump Instrumentation Test Procedures Test Results
4	THE MAGNETIC REFRIGERATOR
4.1	FUNDAMENTAL CONCEPTS
4.2	THE DESIGN OF MAGNETIC REFRIGERATOR
4.2.1 4.2.1.1 4.2.1.2 4.2.1.3 4.2.1.4	The Computer Simulation Model Program Features of the Computer Simulation Model Use of the Computer simulation Model Computer Model Iteration Method Computer Output and Design of Magnetic Refrigerator
5	CONCLUSION
A DDENIDEV	COMPLETE COMPLITER OUTPUT SHEET

ACKNOWLEDGEMENTS

The author wishes to express his gratitude to Dr. Feng-Nan Lin, Dr. Loren Anderson and the NASA/ASEE Summer Faculty Fellowship program for providing him with the opportunity to spend a second fruitful and rewarding summer at the Kennedy Space Center.

Special thanks to Mr. Frank S. Howard for providing a pleasant and friendly working atmosphere and for his encouragement and guidance.

The author is also grateful to the University of Central Florida for offering him a faculty I.D. card and use their library facilities.

ABSTRACT

A supercritical helium pump testing system for a magnetic refrigerator has been built. Details of the supercritical helium pump, the test system, and the test instrumentation are given in this report. Actual pump tests were not run during this ASEE term because of delivery problems associated with the required pump flow meter. Consequently, efforts were directed on preliminary design of the magnetic refrigeration system for the pump.

The first concern with the magnetic refrigerator preliminary design was determining how to effectively use the pump in the magnetic refrigerator. A method to incorperate the supercritical helium pump into a magnetic refrigerator was determined by using a computer model. An illustrated example of this procedure is given to provide a tool for sizing the magnetic refrigerator system as a function of the pump size.

The function of the computer model and its operation are also outlined and discussed.

1 INTRODUCTION

Kennedy Space Center is in the process of developing a highly efficient cryogenic refrigerator to be used to reliquify the liqid hydrogen boil-off. At the present, the boil-off hydrogen is vented and the replacement cost is very high. If the boil-off hydrogen can be successfully reliquified, the savings would be substantial. In addition, there is a possibility that this refrigerator can be used for air conditioning.

The common practice for liquefaction of gases is accomplished by refrigeration method in which gases such as hydrogen gas is compressed in one part of the refrigeration cycle with heat rejected from the gas, then expanded in another part of the cycle to cool and liquefy a portion of the gas. The major disadvantages of the refrigeration method are: (a) low efficiency, (b) large size and (c) large mass. In order to overcome these disadvantages, a system that offers higher efficiency, small size and lower mass is needed. The development of a magnetic refrigeration cycle may offer these advantages.

2 PURPOSE

The purpose of this project was to develop a high efficiency magnetic refrigerator by:

- (a) Setup a supercritical helium pump testing system to determine the performance of the pump,
- (b) Determining a best method to incorperate the pump into a magnetic refirgeration system by using a computer simulation model.

3 PUMP TESTING PROGRAM

3.1 TEST SYSTEM. The testing system was setup by the Boeing Aerospace Operation. It consists of a supercritical helium pump, a supply tank, inlet and outlet pressure transducers, inlet and outlet temperature sensors, a flow meter, a heat exchanger, a pump speed control device, and associated required plumbing. A schematic diagram and a photograph of the facility are shown in Fig. 3.1 and Fig. 3.2 respectively. For cost reduction, the pump was determined to be tested




Figure 3.1. Schematic of Pump Test System



Figure 3.2. Pump Test Facility

with carbon dioxide instead of supercritical helium.

3.1.1 The Supercritical Helium Pump. A cross-section and a photograph of the pump are shown in Fig. 3.3 and Fig. 3.4. The pump was manufactured by Barber-Nichols Engineering Company of Arvada, Colorado (Model BNHeP-04-001). The pump is a partial emission centrifugal pump running at 12,500 rpm. The specific speed of 33 allows the device to operate at 61% efficiency at the design inlet condition of 20K, five atmospheres pressure and 4800 cc/sec. flow rate. The inlet power to the pump is 0.24 Kw at the design differential head of 0.35 atmospheres. This pump is designed to minimize heat leak to ambient and to the pumped fluid allowing the motor to be placed outside the refrigerator with a long 304 stainless steel support tube and drive shaft to separate the pump from ambient conditions to lower conduction and convection losses. The shaft is evacuated and electron-beam seal welded to eliminate internal convective losses. The motor drive is a high efficiency, two-pole, 3 phase, 208 V induction motor designed to operate at 220 Hz frequency. The motor is driven by a modified commercial frequency inverter to take single-phase, 220 V, 60 Hz input and give variable speed up to and beyond 220 Hz (12,500 rpm). The motor end of the drive shaft is supported on a rotating disc-type coupling to allow for slight angular movement of the pump shaft during cool-down without increasing bearing loads.

3.1.2 Instrumentation. The instrument used in this system are listed as follows:

Inlet temperature sensor

Scientific Instruments Inc.

Model #X49WT-04-04

S.N. 876W

Range +50F to +122F

Outlet temperature sensor

Scientific Instruments Inc.

Model #X49WT-04-04

S.N. 875W

Range +50F to +122F

Inlet pressure transducer

Teledyne Taher

Model 2403

S.N. 844340

Range 0 to 150 psig





Figure 3.3. Cross-section of Supercritical Helium Pump

ORIGINAL PAGE IS OF POOR QUALITY,



Outlet pressure transducer

Teledyne Taher

Model 2403

S.N. 834241

Range 0 to 150 psig

Flow meter

Wallace and Tiernan

Straight-through Varea Meter

P.N. TEF5223AT7012XABC40VTX

Presssure:

75 psig

Temperature: 50 - 90F

Flow:

15 to 60 SCFM

Accuracy:

+/- 2% of full scale

Heat exchanger

Foam Heater

Young Radiator Co.

Part #262140

Motor speed control

T.B. Woods Sons Co.

E-TrAC

AC Inverter

- 3.1.3 Test Procedures. Has been documented by the author in the 1987 NASA/ASEE Summer Fellowship final report. (see reference 1)
- 3.1.4 Test Results. The pump will be tested by the Boeing Aerospace Operation Contractor. Due to the absence of flow meter (ordered but not delivered at the time of this writing) test can not be performed.

4 THE MAGNETIC REFRIGERATOR

4.1 FUNDAMENTAL CONCEPTS. The magnetic refrigerator uses a paramagnetic material as the refrigerant. Its operation is based on the natural phenomenon that paramagnetic materials become warmer when they are subjected to a magnetic field and cooler when the magnetic field is removed. A schematic of a recuperative magnetic refrigerator (possible KSC model) is shown in Fig. 4.1. It is a rotational device where the rim of wheel is composed of magnetic working material plates (or packed bed particles). A fluid (such as




Figure 4.1. Magnetic Wheel Design

supercritical helium) is circulated opposite to the direction of rotation of the wheel. Circulated fluid is cooled by the demagnetizing material on the bottom side and is warmed by the magnetizing material on the top side. The operations are as follows:

(a) The magnetic material is adiabatically magnetized as it rotates into the high magnetic field region, heating from Th to Th + Th.

(b) As it rotates through the high magnetic field region the counter flowing fluid cools the magnetic material to temperature

Tc + Tc.

(c) The material is separated from the fluid just before adiabatic demagnetization cools the magnetic material to Tc before the counter flowing fluid warms the rotating magnetic material back to Th to complete the cycle.

The fluid at the hot side of the wheel is cold in the heat exchanger (Heat sink) from Th + Th to Th; the corresponding fluid in the cold heat exchanger (Refrigerator load) is heated from Tc to Tc + Tc.

In order to make the refrigerator efficient, a high efficiency pump is required to circulate the fluid (such as helium gas) through the cycle. In the actual device, the pump should be placed at the location with highest possible temperature.

- 4.2 THE DESIGN OF MAGNETIC REFRIGERATOR. The design of the magnetic refrigerator configurations are basically done by iterations of a computer simulation model.
- 4.2.1 The Computer Simulation Model. The computer model was developed by EG & G Idaho National Engineering Laboratory. It is a model with capacities to run different types of refrigerator with different magnetic materials.
- 4.2.1.1 Program Features of the Computer Simulation Model.

Structured programming

Forty separate subroutines for the follow functions:

- o Refrigerant entropy calculation and table building
- o Refrigerant entropy from table
- o Recuperator fluid data
- o Heat transfer correlations

- o Pressure drop correlations
- o Adiabatic temperature rise
- o Data input and output
- o Plotting
- o Iteration control
- 4.2.1.2 Use of the Computer Simulation Model. This model is an interactive computer program to simulate the performance of a rotor recuperative The computer prompts for data to define the magnetic refrigerator. refrigerator configuration. After all data values are entered (data values and their significance and data entry sheet are shown in Table 4.1, and Fig. 4.2), the program prompts for the name of file containing entropy data. This file contains entropy data for various working materials (see Table 4.2) and MAPS of magnetic field profiles to allow simulation of refrigerator with any circumferential field variation. The program also prompts for the name of a file containing recuperator fluid data. The current file contains data for several recuperator fluids (see Table 4.3). The program will print out a summary of refrigerator performance, and the computer will prompt for the name of a file to write a detailed report of refrigerator configuration and performance. The computer will then ask for increment rotation time. This is useful for comparing one refrigerator to another since each may have optimum performance at different speeds. If rotation time increment are given, a plot file. will be created and an efficiency versus power density will be plotted (see Fig. 4.3). After runs for speeds entered are completed other variables can be changed until desirable configurations of the magnetic refrigerator found by computer iterations.
- 4.2.1.3 Computer Model Iteration Method. See Chart 4.1.
- 4.2.1.4 Computer Output and Design of Magnetic Refrigerator. An example illustrates the procedures of determining the size of refrigerator by using the computer model.

Example: To find the desirable size of the magnetic material plate by selected data input.

No.	Term	Definition	Units
1	CORE MATL	Core material	
2	REGEN FLUID	Regenerator fluid (or recuperator fluid)	
3	ENTROPY OPTN	Entropy calculation option	
4	CORE TYPE	Core type (plate/screen/packed bed)	
5	FIELD MAP	Field map name	
6	LOY FIELD	Low field strength	Teslas
7	HIGH FIELD	High field strength	Teslas
8	HIGH TEMP	Heat pump internal TH (delivery temp.)	k
9	LOY TEMP	Heat pump internal TL (input temp.)	k
10	C FRACT-Tlow	Circumference fraction for recuperative heating	decimal fraction
11	C FRACT-F+	Circumference fraction for field rise	decimal fraction
12	C FRACT-Thi	Circumference fraction for recuperative cooling	decimal fraction
13	C FRACT-F-	Circumference fraction for field drop	decimal fraction
14	ERROR 1		
15	ERROR 2		
16	ERROR 3		
17	FLD CHNG/REV	Field change/rev. (cycles /rev.)	
18	H MULT	Heat transfer coefficient multiplier	
19	DEL P MULT	Presssure drop multiplier	
20	CMULT	Thermal conduction multiplier	
21	PUMP EFF	Pump efficiency	decimal fraction
22	COLD HX DT	Temperature drop in cold heat exchanger	k
23	HOT HX DT	Temperature drop in hot heat exchanger	k
24	MAG TEMP	Magnet operating temperature	k
25	DEWAR	R-yalue of magnet dewar	W/K-m**2
26	CRYO EFF	Efficiency (relative to Carnot COP) of magnet cooler	decimal fraction
27	ROTOR OD	Ratar 00	m
28	ROTOR ID	Rotor ID	m
29	ROTOR HEIGHT	Rotor stack height	m
30		Plate thickness	m
31	PLATE SPACNG	Space between plates	m
32			S/Rev.

Table 4.1. Data Values and Definitions

ORIGINAL PAGE IS OF POOR QUALITY

		DATA INPUT			
CODE MOTI	ואוט	2.000	FLD CHNG/REU	ROTRTION	
CONE PINIL	miatm	1.0000	H MULT	TIMES	
ENTROPY OPTN	MEANFIELD 1.0000	1.0000	DEL P MULT	2.0000	
CORF TVPF	niate	1.0000	C MULT	4.000	
FIFT MAP	NOFIELDMAP 1.0000	1.0000	PUMP EFF	3.000	
I DIII FIFI D	0.000	5.0000	COLD HR DT		
HIGH FIFI D		5.0000	HOT HK DT		
HIGH TEMP		77.000	MAG TEMP		
I DIII TEMP		200.00	DEWAR		
C FRACT-TION	40000	.20000	CRYO EFF		
C FRACT-E+		.16380	ROTOR OD		
C FRACT- T hi		.14920	ROTOR 1D		—
L FRACT F-	10000	.51E-01	ROTOR HEIGHT		
FREDR 1	10000E-05 10.625E-04	0.625E-04	PLATE THICK		_
FRROR 2	10000E-05 10.625E-04	0.625E-04			_
ERROR 3	.10000E-05 1.12700E-03	.12700E-03	PLATE SPACNG		_
nata FILE	MHP. REFRIGERANT DATA	RANT DATA		4	-11
FLUID FILE	MHP.FLUID DATA	ITA		o INT III.	

Figure 4.2. Data Input Sheet

```
Fictitious material with constant specific heat as a function
                                                                                                                                                                Only includes mean field model, which is inaccurate for iron
               X
                11
               points (17 and
                                                                                                                                                                                                                                                                                   Fictitious material with straight T-S line; 400 K Tc.
    point of 40 K
                                                                                                                                                                                          T
C
        Curie
                    Curie
                                                                                                                                                                                           400 and 525
                                                                                                                                                                                 mean field model, not accurate
                                                                                                                                                                                                        16.2 K
                    difference
       nickel with artificial
                                                                                                                                                                                                                                                                   400 X
                                                       304
                                                                  320
                                                                             340
                                                                                        360
                                                                                                    380
                     Gadolinium nickel with
                                                                                                                                                                                                                       Y2(CoxFel-x)17 with To
Y2(CoxFel-x)17 with 40
Y2(CoxFel-x)17 with 38
Y2(CoxFel-x)17 with 52
X2(CoxFel-x)17 with 52
Sm2(CoxFel-x)17 with 4
                                             of
                                                                  of
of
                                                                                        of
                                                                                                                                                                                                                                                                                                  provided at 0 4 9 T.
                                                                                                                                                                                               Mix of Y<sub>2</sub> (CoxFe<sub>1-x</sub>)
Y<sub>2</sub> (CoxFe<sub>1-x</sub>) 17 With
                                                                                                                                                                                                                     vith
                                             000000
nickel
                                                                                         vith
                                             with
                                                                   vith
                                                                               vith
                                                                                                      vith
                                                                                                                                                                                                                                                                                                                           of temperature
                                                                    Gadolinium
                                                                               Gadolinium
                                                                                          Gadolinium
                                                                                                      Gadolinium
            Gadolinium
                                                         Gadolinium
Gadolinium
                                             Gadol inium
                                                                                                                                                                                    Only
                                     Bixed
                                                                                                                                                                                                                                                                                                                CONCP9.480
                                                                                                                                                                                                                                                                                GADOLINIUM
                                                                                                                                                                                                                                                                                           STRGT9.480
                                                                                                                                                                                                  Y2C0400525
                                                                                                                                                                                                                                   Y2COFE400
                                                                                                                                                                                                                                              Y2COFE380
                                                                                                                                                                                                                                                         Y2COFE525
                                                                                                                                                                                                                                                                     SHCOFE400
                                                                                                                                                                                                             Y2C0416.2
                                                                                                                                                                                                                        Y2C0419
                                                                                                        GDTC380
                                                                                                                   GDTC400
                                                                                                                               GDTC420
                                                                                                                                          GDTC440
                                                                                                                                                      CDTC460
                                                                                                                                                                GDTC480
                                                                       GDTC320
                                                                                 GDTC340
                                                                                             GDTC360
                                                GDTC293
                         GDNIMIX
                                                            GDTC304
                                                                                                                                                                                      COBALT
              GDNI40
                                                                                                                                                                             NOEL
    GDNI
```

Table 4.2. Working Material Names in Computer Files

Liquid metal, 339 to 977 K Ferromagnetization Ferromagnetic fluid with 400 K T_C, saturation magnetization of 150 to 200 gauss, and 1-1-Di (ortho zylyl) Ethane (DXE) carrier fluid; 350 to 473 K Ferromagnetic fluid as above, except with Isoparaffinic Dowtherm A heat transfer fluid, 323 to 673 K Liquid 256 to 477 K 4.21 to 8110K 220 to 600 K 255 to 755 K Liquid metal 274 to 523 K Gas at 1 atmosphere, 20 to 80 K hydrocarbon carrier fluid Gas at 1 atmosphere, Gas at 1 atmosphere, Gas at 1 atmosphere, Liquid 200 to 588 K Liquid 200 to 513 K FREON R113 FF-ISOPARH DOWTHERM A HELIUMIATH METHANOL C02-1ATM AIR-1ATM MERCURY H2-1ATM SODIUM FF-DXE WATER

Table 4.3. Recuperator Fluids




Figure 4.3. COP vs Power Density

Pwr density(W/g)*10

CHART 4.1 CALCULATIONAL METHOD

GUESS HEAT CAPACITY RATIO (HCR) - FLUID TO REFRIGERANT

INITIAL TEMPERATURE STACKUP

► ENERGY BALANCE
HEAT TRANSFER RATES
MODIFY TEMPERATURES AS REQUIRED

DETERMINE EFFICIENCY AND POWER DENSITY

FIBINACCI SEARCH; NEW HCR TO APPROACH MAXIMUM EFFICIENCY.

PRINT RESULTS

RUN NEXT SPEED




Figure 4.4. Efficiency vs Rotor Plate Thickness

Efficiency, % Carnot

432

Procedures:

(a) Input selected data into the data sheet.

Major data selected for this example are listed below;

Core material - Gadolinium Nickel Recuperator fluid - Helium at 1 atm. Core type - Plate High temperature - 77K Low temperature - 65K Rotor height - 0.051 m Rotor inside diameter - 0.1492 m Rotor outside diameter - 0.1638 m Plate thickness - 0.625E-4 m

- (b) Run computer with different rotor plate thicknesses.
- (c) Plot efficiency (% of Carnot cycle) versus plate thickness and search for a thickness with highest refrigerator efficiency. (see Fig. 4.4)
- (d) Compare the recuperator flow rate at this thickness with the flow rate of helium pump at highest pump efficiency.
- (e) If the recuperator flow rate of the magnetic refrigerator and the helium pump flow rate are comparable, then, the plate thickness is proper for the helium pump.

Computer Output:

Major outputs are:

COP with cryocooler - 3.95, Efficient (% Carnot) - 61.55 COP w/o cryocooler - 4.19, Efficient (% Carnot) - 65.24 Recuperator flow rare - 0.0147628 kg/s

Design dicisions: The plate thickness versus efficiency curve indicates that at plate theckness equals to 0.000625 m the refrigerator has the highest efficiency and the flow rate is 0.0147628 kg/s. If this flow rate is within the range of helium pump flow rate at highest efficiency then, the plate thickness is proper size for the helium pump.

Complete computer print out (including Entropy table, input data, and output results etc.) are shown in the Appendix section.

5 CONCLUSION

The supercritical helium pump performance information and test results and a revised pump testing procedure will be provided by the Boeing Aerospace Operation Contractor in the future.

The computer model of magnetic refrigerator is a powerful system which has been demonstrated to successfully function in a design and analysis role. Findings from which would suggest the following conclusions:

(a) The magnetic refrigerator only operate with a low temperature difference. Because of this fact that heat transfer should be an important design concern.

(b) The magnetic refrigerator can not operate with packed bed particles, simply because poor recuperative heat transfer. Research to develop improved recuperative heat transfer techniques is needed.

(c) Intimate thermal contact between the magnetic material and the heat

transfer liquid is necessary.

(d) It is desirable to make the exposed area of the magnetic material as large as possible.

REFERENCES

- 1. P. L. Wang, "Experimental Apparatus and Procedures for Testing and Evaluating a Supercritical Helium Pump," NASA/ ASEE Summer Faculty Fellowship Program for Kennedy Space Center, 1987 Research Report, December, 1987
- 2. Harry J. Sauer and Ronald H. Howell, "Heat Pump Systems," John Wiley & Sons, New York 1983
- 3. Rondall F. Barron "Cryogenic Systems," 2nd Edition, Oxford University press, N. Y. 1985

APPENDIX

Complete Computer Output Sheet

		SL, SH, SIN	IL, SINIH, F	L, FH	00	0.00
45.00	98.7412	84.9555	.0000E+00	.0000E+00	.00	9.00
46.31	104.4245	89.9346	.2595E+03	.2273E+03	.00	9.00
47.61	110.1870	94.9692	.5301E+03	.4637E+03	.00	9.00
48.92	115.9982	100.0271	.8106E+03	.7079E+03	.00	9.00
50.23	121.8594	105.1074	.1101E+04	.9597E+03	.00	9.00
51.53	127.7748	110.2123	.1402E+04	.1219E+04	.00	9.00
52.84	133.7263	115.3217	.1713E+04	.1486E+04	.00	9.00
54.15	139.7196	120.4387	.2033E+04	.1760E+04	.00	9.00
55.45	145.7467	125.5528	.2364E+04	.2040E+04	.00	9.00
56.76	151.8031	130.6569	.2703E+04	.2326E+04	.00	9.00
58.07	157.8892	135.7486	.3053E+04	.2619E+04	.00	9.00
59.37	163.9983	140.8181	.3412E+04	.2916E+04	.00	9.00
60.68	170.1299	145.8617	.3780E+04	.3219E+04	.00	9.00
ഖ.98	176.2791	150.8709	.4157E+04	.3526E+04	.00	9.00
63.29	182.4464	155.8431	.4543E+04	.3838E+04	.00	9.00
64.60	188.6267	160.7693	.4938E+04	.4153E+04	.00	9.00
65.90	194.8188	165.6445	.5342E+04	.4471E+04	.00	9.00
67.21	201.0253	170.4673	.5755E+04	.4792E+04	.00	9.00
68.52	204.6784	175.2217	.6003E+04	.5115E+04	.00	9.00
69.82	207.5998	179.9125	.6205E+04	.5439E+04	.00	9.00
71.13	210.5093	184.5317	.6410E+04	.5765E+04	.00	9.00
72.44	213.4007	189.0695	.6618E+04	.6090E+04	.00	9.00
73.74	216.2829	193.5312	.6828E+04	.6416E+04	.00	9.00
75.05	219.1451	197.9028	.7041E+04	.6742E+04	.00	9.00
76.36	221.9922	202.1867	.7257E+04	.7066E+04	.00	9.00
77.66	224.8283	206.3850	.7475E+04	.7389E+04	.00	9.00
78.97	227.6376	210.4809	.7695E+04	.7710E+04	.00	9.00
80.28	230.4357	214.4895	.7918E+04	.8029E+04	.00	9.00
81.58	233.2156	218.4040	.8143E+04	.8346E+04	.00	9.00
82.89	235.9734	222.2214	.8370E+04	.8660E+04	.00	9.00
84.20	238.7194	225.9540	.8599E+04	.8972E+04	.00	9.00
85.50	241.4400	229.5903	.8830E+04	.9280E+04	.00	9.00
86.81	244.1440	233.1421	.9063E+04	.9586E+04	.00	9.00
88.12	246.8341	236.6152	.9298E+04	.9890E+04	.00	9.00
89.42	249.4954	239.9984	.9534E+04	.1019E+05	.00	9.00
90.73	252.1445	243.3120	.9773E+04	.1049E+05	.00	9.00
92.04	254.7729	246.5513	.1001E+05	.1078E+05	.00	9.00
93.34	257.3788	249.7185	.1025E+05	.1108E+05	.00	9.00
94.65	259.9726	252.8275	.1050E+05	.1137E+05	.00	9.00
95.95	262.5389	255.8668	.1074E+05	.1166E+05	.00	9.00

ROTARY MAGNETIC HEAT PUMP: RUN # 1 8-3-88 16:38: 8

CORE MATERIAL GONI RECUPERATOR MATERIAL HELIUMIATM FIELD MAP NAME NOFIELDMAP ENTROPY CALCULATION MEANFIELD CORE TYPE PLATE ROTOR CD (M) .16380 ROTOR ID .14920 CORE HEIGHT .05100 PLATE THICKNESS (M) .6250D-04 SPACING (M) .1270D-03 APPERTURE (M) .6250D-04 HEAT EXCHANGER HOT APPROACH 5.00000 COLD APPROACH 5.00000	SOURCE TEMP (K) DELIVERY TEMPERATURE TEMP ASSYMETRY HIGH FIELD (T) LOW FIELD (T) ROTATION TIME (S) CYCLES/REVOLUTION PUMP EFFICIENCY angl FRACTIONS FIELD RISE RECUPERATIVE HEAT FIELD DROP RECUPERATIVE COOL MAGNET OP TEMP CRYCCCOLER EFF	77.00 .5833 9.00 .00 5.00 2 1.00 .10000 .40000	MULTIPLIERS: DELTA P 1.00 H 1.00 COND K 1.00 ITTERATION CLOSURE ERR1 .1D-05 ERR2 .1D-05 ERR3 .1D-05
---	---	--	--

COP W/O CRYCOCOLER CONDUCTION IN FLUID (W) CONDUCTION IN CORE (W) HEAT INPUT RATE (W) HEAT OUTPUT RATE (W) WORK INPUT TOTAL (W) MAGNETIC WORK (W) FILW WORK (W)	4.19 .513D-02 .811D+00 .2414D+03 .3171D+03 .8030D+02 .80	10.97 603.43 .4259D+06 .3465D+07 1.539 2.021 .9943 .1051D+00
CONFIGURATIONAL INFORMATION:	RECUPERATOR FILID: 52550+00 DENSITY (KG/M**3) .1036D+02

DENSITY (KG/M**3) .1036D+02 OORE MASS (KG) .5255D+00 VISCOSITY (PA-S) .6603D-05

TOTAL ROTOR VOLUME (M**3) .1830D-03

METAL VOLUME (M**3) .6037D-04

FREE VOLUME FRACTION .670

FREE AREA FRACTION .670

REYNOLDS NUMBER (HT CORR) .2198D+04

TOTAL SURFACE AREA .1932D+01 HYDRAULIC DIAMETER (M) .2497D-03

STATE POINTS:	1	3	4	5	7	8
FIJID TEMP (K)	75,508	76.953	77.105	65.014	63.731	64.346
CORE TEMP (K)	75.229	77.119	77.119	66.478	63.583	63.583
ENTROPY (J/KG-K)	219.5376	204.6458	204.6458	167,7690	183.8224	183.8224
FLUID-CORE DT (K)		.166625	.013797	1.464065	.148176	.763194
		77.000				

ROCESSES BETWEEN STATE POIN REGION	1-4	18	5–8	4-5
PINCH POINT TEMPERATURE (K)		75.2294		77.1193
INCH DELTA TEMPERATURE (K)		.278603E+00		.137969E-01
EAT TRANSFER RATE (WATT)	.120708E+03	.256497E+03	.107284E+03	.277801E+03
ORE ENERGY CHANGE (J)	.301770E+02	.256497E+03	.268209E+02	.277801E+03
LUID ENERGY CHANGE (J)	.301822E+02	.256477E+03	.268158E+02	.277822E+03
ISK WORK INTO SYSTEM (J)	517819E-02	.207128E-01	517819E-02	.207128E-01
AT BAL: FLUID-CORE+DISK	.103564E-01	.107650E-12	103565E-01	.112590E-04
ngl (DEGREES)	18.000000	72.000000	18.000000	72.000000
RESSURE DROP (PA)	.844222E+03	.844222E+03	.844222E+03	.844222E+03
TUID FLOW RATE (KG/S)	.147628E-01	.405900E-02	.147628E-01	.405900E-02
-T COEFFICIENT (W/K-M**2)	.196277E+04	.162838E+04	.196277E+04	.162838E+04
LUID-CORE REL VEL. (M/S)	.561366E+01	,166883E+01	.561.366E+01	.166883E+01
EYNOLDS NUMBERS (DELTA P)	2198.	654.	2198.	654